

VTM123

Desktop Mounted Bracket



Features

- Size: 190mm*100mm*54mm
- Dip angle: 45°
- Surface mounted bracket

Installation

Take VTH5221E-H for example.

- With two M3×6 cross recessed countersunk head screws, tighten the metal bracket onto the top two nuts of desktop bracket.
- Please connect wire by reference to the instructions.
- After wiring, guide the wire through wire outlet in the rear or at the bottom of desktop bracket.
- Put the handset VTH along slot at the top of metal bracket, and install it into the bracket.

